
Bookcase WF314529

Assembly Instructions - Please keep for future reference



Safety and Care Advice

Important – Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on the following pages.
- Remove all fittings from the plastic bags and separate them
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before

- During assembly do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.



• To reduce the likelihood of damaging your product please ensure that your

power drill is set on a low torque setting.

Care and maintenance

- Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste.
 Take to your local authority waste disposal centre.

Handy Hints

- Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts
- Regularly check and ensure That all bolts and fittings are tightend properly.


WARNING In order to help prevent overturning – please follow these instructions

To help prevent product toppling over please follow the below steps:-

Use the anti tip stap or wall fixing method provided (if applicable)
Do not allow children to climb or hang on the furniture
Do not open more than one drawer at a time
Do not place heavy items in the top drawers
Do not place heavy items on top of the furniture, unless the furniture has been designed for this purpose

please note that only the anti tip strap is provided.


You will need to provide wall plugs and screws applicable for your wall type



Using Camlocks


Step 1

Connect the male camlock as diected in the assembly instructions using a scewdriver.



Step 2


Push the male camlock into the entry hole.



Step 3

Insert the femle camlock as shown in the instruction.

Note: ensure that the arrow on the top of the camlock points towards the entry hole for the male camlock.



Step 4


Turn the female camlock clockwise with a screwdriver.

You should feel a click when the camlock is locked in place.

The joint is now secure.



Part List: WF314529




Hardware list: WF314529

Please check you have all the panels listed below

Note: The quantitie below are the correcet amount to complete the assembly. In some cases more fittings may be supplied than are required.

A	Female Camlock(15*12) x 38	x1
D	B	3*10mm Screw x 38
G Drawer slider 14" x6	H	6*16mm Screw x24
4*30mm Screw x42	K	4*22mm Screw x4
		•
4*35mm Screw x6 Hex Key M4 x 1	4*20mm Screw x4	8*30mm Screw x8

Tools required




Phillips screwdriver


(medium & large), This is not inclue in the hardware.


Ruler - Use this ruler to help correctly identify the screws


0 5 10 15 20 25 30 35 40 45 50 55 60 65 70 75 80 85 90 95 100 105 110 115 120 125 130 135 140 145 150 155 160 165 170


The screws length is measured from the head to the point (30mm screw shown).




































How to determine the hole positions of the back panel and frame:

1. Up and down distance: Find the position of the top two screws on the back panel, as shown in the picture. Let the frame follow the line formed by these two screws to determine the upper and lower

positions.

2. Left and right distance: You need to make your own judgment. Leave about the same distance on both sides. The picture on the left is an approximate distance reference.

3. After you have confirmed everything, one person is responsible for fixing the position, and then the other person is responsible for drilling holes with screws to fix it.



Step 27

