


ASSEMBLY INSTRUCTIONS

TV Stand

ITEM# AM-21002




If you find any damage after opening, please be sure to take pictures of the damage and contact us. We will help you solve the problem as soon as possible.


THANK YOU

General Assembly Guidelines


- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are : wood dowels , screws and bolts.
- V. A Phillips head screwdriver is required for the assembly of this product .




- VI. Power tools should not be used to assemble this product .




- VII. Insert cam lock into panel tighter with a screwdriver;
Note: Please don't over-tighten the cam lock, otherwise, it will be broken.




- VIII. Concealed hinges are three-way adjustable.



Horizontal
by screw adjustment




In-and-Out
by loosening the hinge-arm
mounting screw or via cam
adjustment





Vertical
Via slots in the mounting
plate or via cam adjustment

Disassemble the slide rail diagram




For disassemble drawer tray, by sliding the tray arm and the tray bracket out. Press and tick the small lever on the tray bracket and carefully pull the two piece apart.

Parts List



















X2



X4

Hardware List

1		Ø8x30	Wooden dowel	16 pcs
2		Ø6x32	Cam bolt	24 pcs
3		Ø15x9.5	Cam lock	24 pcs
4			Sticker	24 pcs
5		Ø3x12	Screw	20 pcs
6			Shelf support pin	8 pcs
7			Handle	3 pcs
8		Ø4x16	Screw	6 pcs
9			Hinge	2 pcs
10		Ø4x12	Screw	12 pcs
11		Ø4x25	Screw	8 pcs
12				4 pcs
13				4 pcs
14		Ø3x12	Screw	24 pcs
15		Ø4x14	Screw	16 pcs




Philips head screwdriver required for assembly
(not included)


*The hardware quantities listed above are required for proper assembly.
Some extra hardware may also have been included.*

Step 1


2:  8 pcs





Step 2

1:  8 pcs


12:  4 pcs



14:  12 pcs



Insert and secure screw(14) to the holes marked in the picture with screwdriver.


Step 3

1:  8 pcs




Step 4

15:  16 pcs




Step 5

2:  8 pcs




Step 6

3:  4 pcs




Step 7

3:  4 pcs




Step 8

3:  8 pcs





Step 9

5:  20 pcs









Step 10

4:  16 pcs



Step 11


2:		8 pcs
7:		2 pcs
8:		4 pcs
13:		4 pcs
14:		12 pcs



Insert and secure screw(14) to the holes marked in the picture with screwdriver.

Step 12



11:		8 pcs
-----	---	-------




Step 13

3:  8 pcs

4:  8 pcs




Step 14




Step 14





6:  8 pcs




Step 15





Step 16

7:		1 pcs
8:		2 pcs
9:		2 pcs
10:		4 pcs




Step 17

10:		8 pcs
-----	---	-------



Step 18



Final Assembly